

QWERTYKEY

H61

PRO

GAMING MECHANICAL KEYBOARD

SPECS AND INSTRUCTION MANUAL

QWERTYKEY.EU

QWERTYKEY.RO

SCAN

TECH SPECIFICATIONS

MODEL: QwertyKey H61

KEY NR: 61 Key

CONNECTIVITY: Type C Wired

STABILIZER TYPE: Plate-mounted

PCB TYPE: Hotswap 3/5 pins, full RGB

ANTI-GHOST: NKRO

POLLING RATE: 1000hz

COMPATIBILITY: WINDOWS/MAC

DIMENSION: 200 x 100 x 38 mm

WEIGHT: 0,6kg

OwertyKey Studio

Connect all your QwertyKey devices in one place. Customize your mouse, adjust performance settings and save personalized profiles. Use OwertyKey Studio directly in your browser or download it for Windows, macOS or Linux.

Fn + Win → Win

Fn + → Reset (3 seconds)

Fn + W ↔ Alt, Ctrl

Fn + B → Delete

Fn + N → Page Down

Fn + Tab → Switch the backlight colors

Fn + ,< → Windows

Fn + .> → Apple

Fn + U → Print Screen

Fn + I → Scroll Lock

Fn + O → Pause

Fn + H → Insert

Fn + J → Home

Fn + \ | → Switch the backlight effect

Fn + P → RGB Pornit/Oprit

Fn + " → Light effect cycle

Fn + ; → Light effect cycle

Fn + Esc → ~

Fn + !@ → F1 (Fn+ 2@ = F2 Fn + += = F12)

Fn + A → Mute

Fn + S → Volum -

Fn + D → Volum +

Fn + F → Multimedia player

Fn +] → RGB effect speed increase

Fn + [→ RGB effect speed decrease

Fn + M → End

Fn + < → Page Up

Fn + G → Calculator

Fn + Z → Previous Track

Fn + X → Next Track

Fn + C → Pause/ Play

Fn + V → Stop

REPLACING KEYCAPS AND SWITCHES

TOOLS INCLUDED

Keycap/Switch Puller

USB Type C cable

INSTALLING SWITCHES

1. Check that all the metallic pins of the switch are perfectly straight.

2. Align the switch vertically.

3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.

4. In case the switch doesn't work, check the metal pins again.

REMOVE SWITCHES

1. Grab your switch puller and align the gripping teeth vertically (on the Y-Axis) at the center of the switch, as shown in the graphic example below.

2. Grab the switch with the switch puller and apply pressure until the switch releases itself from the plate.

3. Using firm but gentle force pull the switch away from the keyboard using vertical motion.

Push straight DOWN

Before installing switches, be sure the pins are clean and straight.

For any technical issues, please send an email to help@qwertykey.ro with your order number and a detailed description of your problem.

QWERTYKEY . EU

QWERTYKEY . RO

SCAN

SPECIFICAȚII TEHNICE

MODEL: QwertyKey H61

NR TASTE: 61 taste

CONECTIVITATE: cablu Type C

TIP STABILIZATOR: Plate-mounted

TIP PCB: Hotswap 3/5 pins, full RGB

ANTI-GHOSTING: NKRO

RATĂ DE POLLING: 1000Hz

COMPATIBILITATE: WINDOWS/MAC

DIMENSIUNI: 200 x 100 x 38 mm

GREUTATE: 0,6 kg

OwertyKey Studio

Conectează toate dispozitivele QwertyKey într-un singur loc. Personalizează mouse-ul, ajustează setările de performanță și salvează profilurile personalizate. Folosește OwertyKey Studio direct in browser sau descarcă-l pentru Windows, macOS sau Linux.

Fn + Win → Win

Fn + → Reset (3 seconds)

Fn + W ↔ Alt, Ctrl

Fn + B → Delete

Fn + N → Derulare în jos

Fn + Tab → Schimbă culorile iluminării de fundal.

Fn + ,< → Windows

Fn + .> → Apple

Fn + U → Captura Ecran

Fn + I → Blocare Ecran

Fn + O → Pauza

Fn + H → Inserare

Fn + J → Acasa

Fn + \ | → Schimbă efectul de iluminare de fundal.

Fn + P → RGB Pornit/Oprit

Fn + " → Light effect cycle

Fn + ; → Light effect cycle

Fn + Esc → ~

Fn + !@ → F1 (Fn+ 2@ = F2 Fn + += = F12)

Fn + A → Mut

Fn + S → Volum -

Fn + D → Volum +

Fn + F → Multimedia

Fn +] → Mărește viteza efectului RGB.

Fn + [→ Micșorează viteza efectului RGB.

Fn + M → Sfarșit

Fn + K → Dendare în sus

Fn + G → Calculator

Fn + Z → Piesa anterioară

Fn + X → Piesa urmatoare

Fn + C → Pauza/ Play

Fn + V → Stop

ÎNLOCUIREA TASTELOR ȘI A SWITCH-URILOR

ACCESORII INCLUSE

Keycap/Switch Puller

USB Type C cable

INSTALARE SWITCH-URI

1. Verifică dacă toate pinii metalici ai switch-ului sunt perfect drepte.

2. Aliniază switch-ul vertical.

3. Apasă switch-ul în jos până auzi un clic. Acest sunet indică faptul că pinii switch-ului s-au fixat pe placa tastaturii.

4. În cazul în care switch-ul nu funcționează, verifică din nou pinii metalici.

ÎNDEPĂRTEAZĂ SWITCH-URILE

Înainte de a instala switch-urile, asigură-te că pinii sunt curați și drepte.

Apasă drept în JOS

1. Ia switch puller-ul și aliniază „dinții” de prindere vertical (pe axa Y), în centrul switch-ului, așa cum este ilustrat în exemplul grafic de mai jos.

2. Prinde switch-ul cu extractorul și aplică presiune până când acesta se desprinde de pe placă.

3. Folosind o forță fermă, dar delicată, trage switch-ul în sus, pe direcție verticală, pentru a-l îndepărta de tastatură.

Pentru orice problemă tehnică, te rugăm să trimiți un email la help@qwertykey.ro menționând numărul comenzii și o descriere detaliată a problemei.

QWERTYKEY . EU

QWERTYKEY . RO

SCAN