QK H100

SPECS AND INSTRUCTION MANUAL

SCAN ME

QK H100

TECH SPECIFICATIONS

MODEL:	QwertyKey H100	ANTI-GHOST:	NKRO
KEY NR:	108 Key	POLLING RATE:	1000hz
CONNECTIVITY:	Type C Wired, Bluetooth, Wireless	COMPATIBILITY:	WINDOWS/MAC
STABILIZER TYPE:	Plate-mounted	DIMENSIONS:	440 x 132 x 40 mm
PCB TYPE:	Hotswap 3/5 pins, full RGB	WEIGHT:	1.2 KG

QWERTYKEY.EU

QWERTYKEY.RO







REPLACING KEYCAPS AND SWITCHES

TOOLS INCLUDED

Keycap Puller
Switch Puller
USB Type C cable

INSTALLING SWITCHES

1. Check that all the metallic pins of the switch are perfectly straight.
2. Align the switch vertically.
3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.
4. In case the switch doesn't work, check the metal pins again.

Push straight DOWN

Before installing switches, be sure the pins are clean and straight.

REMOVE SWITCHES

1. Grab your switch puller and align the gripping teeth vertically (on the Y-Axis) at the center of the switch, as shown in the graphic example below.
2. Grab the switch with the switch puller and apply pressure until the switch releases itself from the plate.
3. Using firm but gentle force pull the switch away from the keyboard using vertical motion.

For any technical issues, please send an email to help@qwertykey.eu with your order number and a detailed description of your problem.

QK H100

SPECIFICAȚII TEHNICE

MODEL:	QwertyKey H100	ANTI-GHOST:	NKRO
NR. TASTE:	108 Taste	POLLING RATE:	1000hz
CONECTIVITATE:	Cablu C, Bluetooth, Wireless	COMPATIBILITATE:	WINDOWS/MAC
TIP STABILIZATORE:	Plate-mounted	DIMENSIUNE:	440 x 132 x 40 mm
TIP PCB:	Hotswap 3/5 pini , full RGB	GREUTATE:	1.2 KG

QWERTYKEY.EU

QWERTYKEY.RO





ÎNLOCUIREA TASTELOR ȘI A SWITCH-URILOR

ACCESORII INCLUSE

Keycap Puller
Switch Puller
USB Type C cable

INSTALARE SWITCH-URI

1. Verifică dacă toate pinii metalici ai switch-ului sunt perfect drepți
2. Aliniază switch-ul vertical.
3. Apasă switch-ul în jos până auzi un clic. Acest sunet indică faptul că pinii switch-ului s-au fixat pe placa tastaturii.
4. În cazul în care switch-ul nu funcționează, verifică din nou pinii metalici.

Apasă drept în JOS

Înainte de a instala switch-urile, asigură-te că pinii sunt curați și drepți.

ÎNDEPĂRTEAZĂ SWITCH-URILE

1. Ia switch puller-ul și aliniază „dinții” de prindere vertical (pe axa Y), în centrul switch-ului, așa cum este ilustrat în exemplul grafic de mai jos.
2. Prinde switch-ul cu extractorul și aplică presiune până când aceasta se desprinde de pe placă.
3. Folosind o forță fermă, dar delicată, trage switch-ul în sus, pe direcție verticală, pentru a-l îndepărta de tastatură.

Pentru orice problemă tehnică, te rugăm să trimiți un email la help@qwertykey.ro menționând numărul comenzii și o descriere detaliată a problemei.