QK61 PRO

western

USER MANUAL

TECH SPECIFICATIONS

MODEL:	QK61 Pro
KEY NR:	61Key Keys
CONNECTIVITY:	USB Wired/BT5.0/2.4G
STABILIZER TYPE:	Plate-mounted
PCB TYPE:	Hotswap 3/5 pins, full RGB
ANTI-GHOST:	NKRO
POLLING RATE:	1000Hz
COMPATIBILITY:	WINDOWS/MAC
DIMENSION:	302x156x38mm
WEIGHT:	0.6kg

SCAN ME

QWERTYKEY.EU

QWERTYKEY.RO

FUNCTION KEY DESCRIPTION

Combination Function Keys

RGB BACKLIT CONTROL

WIRED MODE

Switch the mode button (OFF) to the middle position (USB mode), then connect the USB cable to your computer.
Once the keyboard's backlight turns on and display the default RGB effect, the connection is successfull.

BLUETOOTH PAIRING

QK61 PRO keyboard can connect up to 3 devices at the same time.
Follow these steps to pair the keyboard with your device(s).

1. Switch the mode button (OFF) to Bluetooth, then press and hold FN+Q/W/E for 3~5 seconds to enter pairing mode. The Q/W/E key will flash blue rapidly, indicating the keyboard is ready to connect.
2. Select one of the three options: QK61Pro _1, QK61Pro _2 or QK61Pro _3 to pair, from device's Bluetooth settings.
3. Once the keyboard is connected to your device, Q/W/E key will stop flashing, indicating a successful Bluetooth pairing. To switch between paired Bluetooth devices, simply press FN+Q, FN+W or FN+E.

The Bluetooth connection has a memory feature. When the keyboard is powered off, it will disconnect.
Upon powering it back on, it will automatically reconnect to the last paired device.

2.4Ghz CONNECTION

Switch the mode button to 2.4GHz (OFF)
Press and hold FN+R to enter 2.4GHz pairing mode. The R key will flash green rapidly.
Insert the 2.4Hz dongle into your device's USB port. Once the connection is successful, the R key will stop blinking.
Press and hold FN+R for 3~5seconds to repair the 2.4GHz dongle

SLEEP MODE

If no keys are pressed for 5 minutes, the backlight will turn off.
Any keypress will reactivate the backlight.

After 30 minutes of inactivity in Bluetooth mode, the keyboard will enter deep sleep, disconnecting Bluetooth.
Pressing any key will wake the keyboard.

RESET KEYBOARD

Long press FN + Space 3 seconds to reset the keyboard.

LOCK/UNLOCK WIN_L & CAPSLOCK KEYS

Press FN + WIN_L or Caps Lock key to lock or unlock the key function.

The RGB LED ex the Caps Lock and Win_L keys will turn white when locked. When unlocked, the backlight will follow the active lighting effects.

BATTERY CHARGING

FN+Ins with default RGB effect under wireless connection, the FN key will flash red when the keyboard's battery is low (below 3.3V) Checking the battery level under the wireless connection, a steady red light will display while charging, and it will turn green when charge to full.

BATTERY CHECKING

FN + Shift_R - Battery level indicator. From 1l to 10 stands for 10%-100%

CUSTOM CONFIGURATION

QK61 Pro keyboard support web-driven software to configure and mapping the keys, and setting the Macro.
Please visit: software.qwertykey.ro

REPLACING KEYCAPS AND SWITCHES

TOOLS INCLUDED

Keycap Switch Puller
USB Type C cable

INSTALLING SWITCHES

1. Check that all the metallic pins of the switch are perfectly straight.
2. Align the switch vertically.
3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.
4. In case the switch doesn't work, check the metal pins again.

Push straight DOWN

Before installing switches, be sure the pins are clean and straight.

REMOVE SWITCHES

1. Grab your switch Removal Tool and align the gripping teeth vertically (on the Y-Axis) at the base of the switch, as shown in the example graphic on the right.
2. Grab the switch with the switch puller and apply pressure until the switch releases itself from the plate.
3. Using firm but gentle force pull the switch away from the keyboard using vertical motion.

For any tehnical issues, please send an email to help@qwertykey.ro with your order number and a detailed description of your problem.