QK80

SPECS AND INSTRUCTION MANUAL

QWERTYKEY80 ASTRO
QWERTYKEY80 WAR
QWERTYKEY80 ETHER
QWERTYKEY80 ENEBA

SCAN ME

QWERTYKEY80

SPECS AND INSTRUCTION MANUAL

TECH SPECIFICATIONS

MODEL:	QwertyKey 80
KEY NR:	87 Key TKL
STRUCTURE:	Gasket mounted
STABILIZER TYPE:	Plate-mounted
PCB TYPE:	Hotswap 3/5 pins, full RGB
BATTERY CAPACITY:	4000mAh
PLATE MATERIAL:	Polycarbonate
CONNECTIVITY:	Type C Wired, Wireless2.4 & Bluetooth
ANTI-GHOST:	N80 in all modes
POLLING RATE:	1000hz in Type-C Wired & Wireless 2.4G
COMPATIBILITY:	WINDOWS/MAC
DIMENSION:	363 x 135 x 40.5 mm
WEIGHT:	≈ 1kg

SCAN ME

HELP@QWERTYKEY.RO
QWERTYKEY.EU
QWERTYKEY.RO

WINDOWS SHORTCUTS

FN + F1	Screen Brightness -	FN + F5	Search	FN + F9	Next Track
FN + F2	Screen Brightness +	FN + F6	Previous Track	FN + F10	Mute
FN + F3	Task	FN + F7	Previous Track	FN + F11	Volume -
FN + F4	My Computer	FN + F8	Play/Pause	FN + F12	Volume +

MACOS SHORTCUTS

FN + F1	Screen Brightness -	FN + F5	Search	FN + F9	Next Track
FN + F2	Screen Brightness +	FN + F6	Screen Shot	FN + F10	Mute
FN + F3	Task	FN + F7	Previous Track	FN + F11	Volume -
FN + F4	Open the dropup board	FN + F8	Play/Pause	FN + F12	Volume +

KEY COMBINATIONS

FN + ESC	Reset Keyboard	FN + 1	Short Press to Switch BT1 Long Press to Pair
FN + WIN	Lock/Unlock Win Key	FN + 2	Short Press to Switch BT2 Long Press to Pair
FN + 4	Short Press to Switch to 2.4G Mode; Long Press to Pair Devices	FN + 3	Short Press to Switch to BT3 Long Press to Pair

LIGHT EFFECTS

FN + Ins	Turn On/Off the Backlights effects	FN + ↑	Backlights Brightness +
FN + ↓	Turn On/Off the Backlights	FN + ←	Backlights Brightness -
FN + Del	Backlights Hue +		
FN + Home	Backlights Sat +	Other Backlights control FN Shortcuts	
FN + End	Backlights Sat -	# The side lighting effects following the main effects	

SWITCH BUTTON INSTRUCTION

1. Switch to 2.4G and press FN + 4 to enter the 2.4G wireless mode
2. Switch to BT and press FN + ↓/↑ to enter the Bluetooth mode
3. Switch to USB, it will turn off the battery and enter the wired mode, connect the USB cable to use
4. Switch to Mac to enter the MAC OS
5. Switch to Win to enter the Windows OS



SCREEN CONTROL INSTRUCTION

FN + Backspace	Turn On/Off the screen
FN + ← or →	Switch to display the User GIF

Download the software for screen control from: qwertykey.eu / qwertykey.ro

10/21 11:20:35	Display the date; Display the time		Display the wired mode
BAT	Display the battery status; When low battery (<20%), flash 3 times and turn off		Display the mac OS/iOS/iPadOS
			Display the 2.4G wireless mode
			Display the Caps Lock/Unlock
	Display the Windows OS		Display the Bluetooth mode
	Display the MAC OS		Display the Number Lock/Unlock

AUTO SLEEP MODE

If with no operation in dark under 8V or 2.4GHz Wireless mode, the keyboard board and screen will enter sleep mode, the keyboard will enter deep sleep mode, and the screen will enter sleep mode, in the Bluetooth device, by press any key to awaken it, and then the backlit and screen will turn on.

VIA CONNECTION

1. QwertyKey 80 Keyboard support using VIA programme to configure and mapping the keys via wired mode.Please visit https://github.com/owerteam/qwr-via-release/releases to download the latest VIA programme (Windows/macOS/Linux) and Vial(Linux) users.app to configure it.
2. Download the QwertyKey80.JSON file from QWERTYKEY80 official website, upload the file to the VIA APP or Web then you can start to configure it.
3. When the testing is completed, and the keyboard connected by USB, in the software, click Save to save all your keyboard, by "Configure" tab will display the layout and mapping the keys.

The QwertyKey 80 Keyboard memory is persistent. The setting will be saved and will be saved after disconnected the VIA APP.

REPLACING KEYCAPS AND SWITCHES

TOOLS INCLUDED

Keycap Switch Puller
Dongle wireless

Extra Keycaps for MACOS layout
USB Type C to USB Type A cable

INSTALLING SWITCHES

1. Check that all the metallic pins of the switch are perfectly straight.
2. Align the switch vertically.
3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.
4. In case the switch doesn't work, check the metal pins again.

Push straight Down

Before installing switches, be sure the pins are clean and straight.

REMOVE SWITCHES

1. Grab your switch Remover Tool and align the gripping teeth vertically (on the 11 And at the center of the switch, as shown in the pictures at right in drawing.
2. Grab the switch with the switch puller and apply pressure until the switch releases itself from the plate.
3. Using hot air gentle blow just the switch away from the keyboard using vertical motion.

For any technical issues, please send an email to help@qwertykey.ro with your order number and a detailed description of your problem.

QWERTYKEY80

SPECIFICAȚII ȘI MANUAL DE INSTRUCȚIUNI

SPECIFICAȚII TEHNICE:

MODEL:	QwertyKey 80
NUMĂR TASTE:	87 taste
STRUCTURA:	Gasket mounted
TIP STABILIZATOR:	Plate-mounted
TIP PCB:	Hotswap 3/5 pins, full RGB
CAPACITATE BATERE:	4000mAh
MATERIAL PLACĂ:	Policarbonat
CONECTIVITATE:	Type C cu fir, Wireless 2.4 & Bluetooth
ANTI-GHOSTING:	N80 în toate modurile
RATA DE POLING:	1000hz în modul Type-C Wired & Wireless 2.4G
COMPATIBILITATE:	WINDOWS/MAC
DIMENSIUNI:	363 x 135 x 40.5 mm
GREUTATE:	≈ 1kg

SCAN ME

HELP@QWERTYKEY.RO
QWERTYKEY.EU
QWERTYKEY.RO

SCURTĂTURI WINDOWS

FN + F1	Luminozitate ecran -	FN + F5	Căutare	FN + F9	Pasul următoarea
FN + F2	Luminozitate ecran +	FN + F6	Captură ecran	FN + F10	Mute
FN + F3	Task	FN + F7	Pasul anterioară	FN + F11	Volum -
FN + F4	Computerul meu	FN + F8	Pauză/ Redare	FN + F12	Volum +

SCURTĂTURI MACOS

FN + F1	Luminozitate ecran -	FN + F5	Căutare	FN + F9	Pasul următoarea
FN + F2	Luminozitate ecran +	FN + F6	Captură ecran	FN + F10	Mute
FN + F3	Task	FN + F7	Pasul anterioară	FN + F11	Volum -
FN + F4	Tablou de pornire	FN + F8	Pauză/ Redare	FN + F12	Volum +

COMBINAȚII DE TASTE

FN + ESC	Resetează tastatura	FN + 1	Apăsând scurt pentru a comuta pe BT1; Apăsând lung pentru a asocia
FN + WIN	Blochează/ deblochează tasta Win	FN + 2	Apăsând scurt pentru a comuta pe BT2; Apăsând lung pentru a asocia
FN + 4	Apăsând scurt pentru a comuta pe modul 2.4G; Apăsând lung pentru a asocia	FN + 3	Apăsând scurt pentru a comuta pe BT3; Apăsând lung pentru a asocia

EFECTE DE LUMINĂ

FN + Ins	Aprinde/ stinge de iluminare	FN + ↑	Luminozitatea iluminării +
FN + ↓	Pornește/Oprește iluminarea de fundal	FN + ←	Luminozitatea iluminării -
FN + Del	Nuanța iluminării de fundal +		
FN + Home	Saturația iluminării +	Alte setări ale control al iluminării prin software-ul VIA	
FN + End	Saturația iluminării -	# Efectele de iluminare laterală urmează efectele principale	

INSTRUCȚIUNI PENTRU BUTONUL DE COMUTARE

1. Comutați pe 2.4G și apasă FN + 4 pentru a intra în modul wireless 2.4G
2. Comutați pe BT și apasă FN + ↓/↑ pentru a intra în modul Bluetooth
3. Comutați pe USB, acesta va dezactiva bateria și va trece în modul cablat. Conectează cablul USB pentru a fi folosit.
4. Comutați pe Mac pentru a intra în modul MacOS
5. Comutați pe Win pentru a intra în modul Windows

INSTRUCȚIUNI DE CONTROL AL ECRANULUI

FN + Backspace	Pornește/Oprește ecranul
FN + ← or →	Comutați pentru a afișa GIF-ul

Descărcați software-ul pentru ecranul ecranului de pe: qwertykey.eu / qwertykey.ro

10/21 11:20:35	Afișează data; Afișează ora		Afișează modul cablat
BAT	Afișează starea bateriei; Dacă bateria este redusă (<20%), se aprinde de 3 ori și se stinge		Afișează modul macos/iphone/ipados
			Afișează modul wireless 2.4G
			Afișează blocarea/deblocarea Caps Lock
	Afișează Windows OS		Afișează modul Bluetooth
	Afișează MAC OS		Afișează blocarea/deblocarea Num Lock

MODUL SLEEP AUTOMAT

Dacă în ac ebscuritate nici o lucrare timp de 8 minute în modul 8V sau wireless 2.4GHz, tastatura tastatura și ecranul se vor atinge scenariul. Dacă nu se efectuează nici o operație timp de 20 de minute, tastatura va intra în modul standby, și se va deconecta de la dispozitivul Bluetooth. Apasă orice tastă pentru a o trezi, iar tastatura și ecranul se vor aprinde din nou.

CONEXIUNE VIA

1. Tastatura QwertyKey 80 suportă configurarea și cartografierea tastelor prin intermediul modului cablat. Vă rugăm să vizitați https://github.com/owerteam/qwr-via-release/releases pentru a descărca cea mai recentă aplicație VIA pe PC-ul dvs. sau vă rugăm să accesați direct https://usevial.app/ pentru a o configura.
2. Descarcă fișierul QwertyKey80.JSON de pe QWERTYKEY80 site-ul oficial, și apoi în VIA APP sau în Web, apoi poți începe să configurezi.
3. Când testarea este completă și tastatura este conectată prin USB, în software, și apoi faceți clic pe „Save" pentru a salva toate tastele. Tabul „Configure" Configurați. Va fi afișat diagrama și mapare tastelor.

Memoria tastaturii QwertyKey 80 este persistentă. Setarea va fi salvată și va fi salvată după deconectarea aplicației VIA.

Pentru orice problemă tehnică, vă rugăm să trimiteți un email la help@qwertykey.ro cu indicarea numărului comandă și o descriere detaliată a problemei.

ÎNLOCUIREA CAPACELOR DE TASTE ȘI A SWITCH-URILOR

ACCESORII INCLUSE

Dispozitiv Switch Puller
Dongle wireless

Extra taste pentru MACOS
USB Type-C - USB Type A cablu

INSTALAREA SWITCH-URILOR

1. Verifică dacă toți pinii metalici ai switch-ului sunt perfect drepți.
2. Aliniați comutatorul vertical.
3. Apăsați comutatorul în jos până când auziți un clic. Aceasta înseamnă că clapele comutatorului s-au prins de placa tastaturii.
4. În cazul în care comutatorul nu funcționează, verificați din nou pinii metalici.



Împingeți direct în jos

Înainte de a instala comutatoarele, asigurați-vă că pinii sunt curați și drepți.

ÎNDEPĂRTAȚI SWITCH-URILE

1. Prindeți instrumentul de trăgătoare a comutatorului și aliniați dinții de prindere vertical (pe ace 11 și în centrul comutatorului, așa cum este afișat în imaginile de la dreapta.
2. Prindeți comutatorul cu instrumentul de trăgătoare a comutatorului și aplicați presiune până când comutatorul se eliberează de pe plăci.
3. Folosind o fără fierbinte, iar delicată, suflați comutatorul departe de tastatura folosind o mișcare verticală.